SD NAND ŨỸ ^ 9˜ ®



Bits	Description	Width
379:376	mode 0 - The function which can be switched in function group 1. mode 1 - The function which is result of the switch command, in function group 1. 0xF shows function set error with the argument.	4
375:368	Data Structure Version 00h – bits 511:376 are defined 02h-FFh = reserved	8
367:352	Reserved for Busy Status of functions in group 6. If bit [i] is set, function [i] is busy. This field can be read in mode 0 and mode 1	16
351:336	Reserved for Busy Status of functions in group 5. If bit [i] is set, function [i] is busy. This field can be read in mode 0 and mode 1	16
335:320	Reserved for Busy Status of functions in group 4. If bit [i] is set, function [i] is busy. This field can be read in mode 0 and mode 1	16
319:304	Reserved for Busy Status of functions in group 3. If bit [i] is set, function [i] is busy. This field can be read in mode 0 and mode 1	16
303:288	Busy status of functions in group 2. If bit [i] is set, function [i] is busy. This field can be read in mode 0 and mode 1	16
287:272	Reserved for Busy Status of functions in group 1. If bit [i] is set, function [i] is busy. This field can be read in mode 0 and mode 1	16
271:0	Reserved (All '0')	272

杭州瀚海微科技有限公司
www.hanhai-tech.com

ŵ ß Â ч ˘ h
Ь ˊ Â ע Ɒ ˘ ɢ ˊ Â

₱ خي ƀ Ţ ® ˘ ғ خيف Ţ نج ╠ ₱ ˍ˘ ↕ ч ₱ Â
ƀ ٦ ψ ف ₱ ч Â

Argument	Busy Status	Status Code	Comment
0	Don't Care	0	Default function can always be switched.
Supported function	Ready	=Arg.	Status indicates the same function number as specified in the argument, which means successful function change.
[illegible]	[illegible]	Busy	Current Selected [illegible] current selected function.
[illegible]	Not Supported function	Don't Care	Fh	If one of the function groups in code Fh, switch requests to all are canceled and the rest of Status Data Structure should be
function	Fh	Don't Care	Current Selected	Status indicates current selected

Status Code of Mode 1 to Supported Function Group

Argument	Busy Status	Status Code	Comment
Status always indicates 0.		0	Don't Care	0
Status always indicates Fh.		Eh-1h	Don't Care	Fh
Status always indicates 0.		Fh	Don't Care	0

Status Code of Mode 0 and 1 to Unsupported Function Group

杭州瀚海微科技有限公司
www.hanhai-tech.com